

Bosch Motronic THOR Emulator fitting instructions.

Install as per the picture below.

Please note: In some ECUs there is no capacitor at the pad where the black wire is connected. This was a factory revision so just solder the wire to the solder pad.

